

Set includes plates, handles and cylinders (where applicable). Multi Point lock mechanism is not included.  
Andersen®

<b>Keyed with American Cylinder</b> (for Active Door, Schlage® Keyway Standard, Weiser® Keyway Optional, Rekeyable)	
<p>1 1/2" x 11" Plates, Product Codes 1311, 1331, 1351, 1371, 13A1</p>	<p>2" x 10" Plates, Product Codes 1321, 1341, 1361, 1381, 13B1</p>
<b>Non-Keyed, Passage</b> (for Semi-Active Door)	
<p>1 1/2" x 11" Plates, Product Codes 1312, 1332, 1352, 1372, 13A2</p>	<p>2" x 10" Plates, Product Codes 1322, 1342, 1362, 1382, 13B2</p>
<b>Non-Keyed, American Style Thumbturn Inside</b> (for Active Door)	
<p>1 1/2" x 11" Plates, Product Codes 1313, 1333, 1353, 1373, 13A3</p>	<p>2" x 10" Plates, Product Codes 1323, 1343, 1363, 1383, 13B3</p>
<b>Non-Keyed, Fixed Handle Outside, Operating Handle Inside</b> (for Semi-Active Door)	
<p>1 1/2" x 11" Plates, Product Codes 1314, 1334, 1354, 1374, 13A4</p> <p>Fixed</p>	<p>2" x 10" Plates, Product Codes 1324, 1344, 1364, 1384, 13B4</p> <p>Fixed</p>
<b>Dummy Pair</b> (for Non-Active Door)	
<p>1 1/2" x 11" Plates, Product Codes 1315, 1335, 1355, 1375, 13A5</p> <p>Fixed</p>	<p>2" x 10" Plates, Product Codes 1325, 1345, 1365, 1385, 13B5</p> <p>Fixed</p>